### Annual Maintenance Procedure

### FOR USE WITH CD10, CD10/AD, CD12 & CD12/AD

Maintenance of the ozone system is critical to its longevity and operating efficiency. Follow the steps below to perform the preventative annual maintenance. If you have additional questions regarding the maintenance of your ozone installation, please consult the operation manual or contact your dealer.

### **Before you start:**

#### **System Shutdown Procedures**

- **Step 1:** Turn off power to any peripheral system hydraulic components and air prep system.
- **Step 2:** Turn the Main Power switch on the ozone generator to the "OFF" position. The LED display on the front cover should *not* be illuminated.
- Step 3: Disconnect the power to the ozone system at the service disconnect box (if so equipped), main circuit breaker or by disconnecting the power cord.


### **Recommended Tools**

Nut Drivers: 5/16", 11/32"
Screwdrivers: Phillips and flat-head
O-Ring Removal Pick
Hex Key: 7/64"
Marking Pen
Wrench: 5/8" or adjustable
1" Ball hone (optional)
Channel lock-type Pliers
Snap Ring Pliers (for CD10/AD & CD12/AD)
Cloth Shop Towel
Denatured Alcohol
Teflon Sealing Tape

### Video Walkthroughs

Visit our video channel at: <a href="http://www.youtube.com/ClearWaterTech">http://www.youtube.com/ClearWaterTech</a>
These, and other procedures are shown.







### Included in this maintenance kit:

Pictured are the contents of a CD10/AD maintenance kit and an overview image of the CD10/AD.

Numbered items correspond to descriptions below and their installed locations within the ozone generator.

CD10, CD12 & CD12/AD systems will have similar maintenance kits and generator layouts. They will have differences in quantity of parts, however the steps will be the same.

The CD10 & CD12 kits will not have the media for internal air dryers (#6 & #7). The CD12/AD kit will not have indicating media (#7)

CD12 & CD12/AD models will have a second set of o-rings (#5), as the units have two reaction chambers.

### **Maintenance Will Involve the Following:**

- 1. Cooling Filter: Clean or replace the cooling fan filter elements as required.
- **2. Inline Particulate Filter:** Remove colored protective caps before installing the new filter. Re-tape threads with Teflon tape. Orientation is universal.
- **3. Check Valves:** Replace both check valves, one at the ozone generator and one at the injector. Make note of check valve direction before removing old check valve and reinstall new valve in same direction. Re-tape threads with Teflon tape.
- 4. Fuses: Save the replacement fuses for use as needed.
- **5. Reaction Chamber O-Ring Replacement:** See page 2 for reaction chamber maintenance instructions.
- **6. Air Dryer Media:** See page 3 for air preparation maintenance instructions.
- 7. Indicating Media: See page 3 for air preparation maintenance instructions.



## Annual Maintenance Procedure

FOR USE WITH CD10, CD10/AD, CD12 & CD12/AD

1" Reaction Chamber - Exploded View

End Cap Retaining

Ozone Outlet Fittina

Screws and Washers

Heat Sink and

Glass

Oxygen Inlet Fitting

### **Reaction Chamber Removal and Disassembly:**

Note: Read through all the steps before disassembling the reaction chamber.

- Step 1: Make sure all power to the ozone generator has been disconnected according to the "System Shutdown Procedures" outlined above.
- **Step 2:** Disconnect the high voltage lead from the reaction chamber(s).
- Step 3: Disconnect the tubing connections on both ends of the reaction chamber(s).
- **Step 4:** Remove the 4 nuts securing each chamber and remove the reaction chamber from ozone generator.
- **Step 5:** Make note or mark the position of the end caps and their elbow fittings on the reaction chambers, during re-assembly the end
  - caps will need to return to original positions. The orientation of the end caps and the chamber itself is different between the two CD12 chambers.


High Voltage End

Cap and O-rings

- **Step 6:** Remove retaining screws and washers from the two end caps (3 each).
- Step 7: Using a gentle back-and-forth twisting motion, remove the non-high voltage end cap (the one without the high voltage attachment screw) from the heat sink/cathode assembly. A flat-head screwdriver may be used to gently pry the end cap off, as long as equal pressure is applied to each side of the end cap.
- **Step 8:** Remove the high voltage end cap and dielectric from the heat sink/cathode assembly.
- Step 9: The high voltage end cap can be removed by holding the glass and turning the end cap counter-clockwise approximately 6 turns. Pull the end cap off the glass. Push the contact brush out of the dielectric glass. A screwdriver can be used to push the brush, and pliers to pull it out once the opposing end is exposed.
- Step 10: Inspect the dielectric, end caps and cathode for breakage, corrosion or debris; then follow the assembly and re-installation steps below.

### **Reaction Chamber Assembly and Re-installation:**

- Step 1: Remove o-rings from end caps, clean the dielectric glass, end caps and interior of the stainless steel cathode cylinder. Use denatured alcohol, shop towels to clean and be sure to remove all old o-ring debris. A 1" ball hone can be used to clean the major debris out of the cathode if there is heavy buildup.
- Step 2: Prepare the end caps for re-assembly by replacing the o-rings. Thread the hex brush adapter nut, with contact brush attached, onto the end of the high voltage end cap (cap with the high voltage attachment screw) center screw. Re-tape the threads of the elbow fittings if needed.
- Step 3: Using a gentle twisting motion, press the non-high voltage end cap onto the heat sink/cathode assembly until flush with the heat sink cooling fins. Turn the end cap to the correct orientation.
- Step 4: Slide the three end cap retaining screws with washers through the holes in the non-high voltage end cap, aligning them with the heat sink screw bosses. Thread screws into screw bosses until heads are snug against the end cap.
- Step 5: Next we focus on assembling the rest of the subcomponents, before installing them into the reaction chamber. Slowly insert the brush (installed onto the high voltage end cap) into the dielectric glass. Note: Go slowly in order to prevent or minimize bending the center wire of the brush during this procedure. It is normal for the bristles to bend flat against the dielectric glass. Fully seat the dielectric glass into the high voltage end cap. Clean the glass with denatured alcohol once more, and do not retouch the glass without re-cleaning.
- Step 6: Hold the reaction chamber upright on a flat surface, empty high voltage side up. Grasp the high voltage end cap and lower the glass into the reaction chamber. Press directly downwards on the high voltage end cap to fully seat the dielectric assembly; the end caps should be flush with the heat sink cooling fins. Turn the end cap to the correct orientation.
- Step 8: Slide the three end cap retaining screws with washers through the holes in the end cap, aligning them with the heat sink screw bosses. Thread screws into screw bosses until heads are snug against the end cap.
- Re-install the complete reaction chamber assembly into the ozone generator by securing the reaction chamber to its mounts, securing delivery line and connecting the high voltage insulated wire.



# Annual Maintenance Procedure FOR USE WITH CD10, CD10/AD, CD12 & CD12/AD

### **Air Preparation System**

CD10/AD and CD12/AD only: The tan colored beads are an air dryer desiccant. The blue and white media is typically called indicating media. It is silica gel and acts as an indicator of the health of the air dryers.

If the air dryer desiccant requires replacement, moisture will be present in the dryer's output. The silica media will absorb the moisture and will change the blue crystals to pink, then white. If the indicating media has changed color, this maintenance of replacing the media should resolve the issue and restore proper ozone output. If the indicating media has yet to change color, it is recommended to replace the air dryer media for preventative maintenance. The indicating crystals can be saved for future use, or installed; it is optional in this case.

For steps regarding replacement of these medias see "Air Dryer Desiccant Replacement" and "Indicating Media Replacement" below.

**CD10** and **CD12** only: Your air prep system will consist of either a PSA Oxygen Concentrator or LPSA Dry Air. Compressors, PSA Oxygen Concentrator or LPSA Dry Air: Following the procedures outlined in the compressor rebuild kit, rebuild the two compressor heads and replace all filters.

Note: Manufacturers' recommended interval is 5,000 to 12,000 hours of operation. Compressor performance and/or operating conditions in the equipment area will dictate the required frequency of this procedure.

### **Air Dryer Desiccant Replacement**

Note: You will need to remove the unit from the wall in order to pour out the media. Allow the air dryer chambers to cool completely and read all steps before continuing.

- Step 1: Straighten out the ends of the dryer chambers using pliers.
- Step 2: Using a snap ring tool, remove the top snap rings.
- Step 3: Remove the top screens; the o-ring pick is handy for this. The bottom snap ring may be left remaining within the air dryer chambers.
- Step 4: Turn the ozone generator over to pour the old sieve material from the dryer chambers and dispose. Note: When removing the sieve material, be sure not to discard the bottom screens.
- Step 5: Re-seat/Re-install the bottom screens. Note: The heater rod must be put through the center of the bottom screens.
- Step 6: Fill chamber with new sieve material to 3/4" to 1" below the top of the dryer chambers. You will have more media than needed.
- Step 7: Re-install the top screens.
- Step 8: Using a snap ring tool, place the top snap rings snug against the top screen.
- Step 9: Bend the ends of the dryer chambers in-ward for added retention of the sieve material (optional).
- Step 10: The ozone generator must be turned on for 24 hours prior to system start-up to eliminate any moisture trapped in the new sieve material.

### Indicating Media Replacement (CD10/AD only)

- Step 1: Using wrench, loosen and disconnect the compression fitting located at the top of the indicating media chamber.
- Step 2: With a flat-head screwdriver, unlock the two gray clamps securing the indicating media chamber.
- **Step 3:** Pull the chamber free of the clamps, the chamber will only be held within the unit by the bottom cap. Rotate the chamber downwards to position the bottom cap to be at the top of the chamber.
- Step 4: Secure the bottom cap with channel lock pliers and turn the chamber counter-clockwise to unscrew it. Be mindful to not spill the indicating media.
- Step 5: Remove the indicating chamber from the unit, remove the interior screen and dispose of the media.
- **Step 6:** Remove the Teflon tape from the bottom cap's threads and re-tape the threads with 2-3 wraps.
- Step 7: Refill the indicating chamber with new blue and white indicating crystals. You will have more media than needed.
- Step 8: Replace the interior screen and reinstall the chamber following steps 1 through 4 in reverse order.

